

Channel Frequency Table

FR1 <i>a</i>	CH1	----	5865	----	MHz
	CH2	----	5845	----	MHz
	CH3	----	5825	----	MHz
	CH4	----	5805	----	MHz
	CH5	----	5785	----	MHz
	CH6	----	5765	----	MHz
	CH7	----	5745	----	MHz
	CH8	----	5725	----	MHz
FR2 <i>b</i>	CH1	----	5733	----	MHz
	CH2	----	5752	----	MHz
	CH3	----	5771	----	MHz
	CH4	----	5790	----	MHz
	CH5	----	5809	----	MHz
	CH6	----	5828	----	MHz
	CH7	----	5847	----	MHz
	CH8	----	5866	----	MHz
FR3 <i>E</i>	CH1	----	5705	----	MHz
	CH2	----	5685	----	MHz
	CH3	----	5665	----	MHz
	CH4	----	5645	----	MHz
	CH5	----	5885	----	MHz
	CH6	----	5905	----	MHz
	CH7	----	5925	----	MHz
	CH8	----	5945	----	MHz
FR4 <i>F</i>	CH1	----	5740	----	MHz
	CH2	----	5760	----	MHz
	CH3	----	5780	----	MHz
	CH4	----	5800	----	MHz
	CH5	----	5820	----	MHz
	CH6	----	5840	----	MHz
	CH7	----	5860	----	MHz
	CH8	----	5880	----	MHz
FR5 <i>A</i>	CH1	----	5658	----	MHz
	CH2	----	5695	----	MHz
	CH3	----	5732	----	MHz
	CH4	----	5769	----	MHz
	CH5	----	5806	----	MHz
	CH6	----	5843	----	MHz
	CH7	----	5880	----	MHz
	CH8	----	5917	----	MHz